




Instruction Sheet for Connecting


**EX PUMP - FILTER HEAD** 


## **NECESSARY TOOLS**















#### FILTER TO PUMP CONNECTION







### FILTER TO PUMP CONNECTION







#### FILTER TO PUMP CONNECTION











# FILTER TO PUMP CONNECTION USING FLANGE





## FILTER TO PUMP CONNECTION USING FLANGE

